

### MR-JE

			<b>MR-JE</b>		
10	P+		10	PP	1
11	P-		11	PG	
13	S+		35	NP	2
14	S-		36	NG	
2	A+	A	4	LA	A
3	A		5	LAR	
4	B+	B	6	LB	B
5	B-		7	LBR	
6	Z+	Z	8	LZ	Z
7	Z-		9	LZR	
1	+24V	+24V	20	DI COM	DC24V +
9	OV	24V	46	DOCOM	DC24V -
15	ALRM		48	ALM	
8	SON		15	SON	
12	BRAKE		23	MBR	
CNI 42 EM2 43 LSP			44(LSN) 46 DCOM		

PA01		***0
PC24	BRAKE (CNI-23)	05
PA05		8000
PA13		**00(
PA14		0 1
PA15		8000
PA21		1***
PC19		**00 **01